


# Installation Instructions





## Notice:

1. only use soft fabric to clean the taps, no acid and alkaline material for cleaning.
2. cartridge and diverter are tested in the factory, no self assembly and disassembly.
3. underground pipes should be installed strictly according to the manual, exchange of cold water pipe and hot water pipe is not allowed.
4. water inlet pipes must be cleaned before tap installation, impurities could destroy the cartridge, diverter and aerator.
5. CAUTION: when turn on the tap, please turn to cold first, then adjust to suitable temperature, to avoid scald.
6. gloves are needed during installing the tap.


## Problems and Solutions:

1. if water flow is not enough, please be sure the angel valve are opened.
2. if water column is not in regular shape, please be sure the aerator is cleaned.
3. if temperature not adjustable, please be sure the angel valve and connection pipe is correctly installed.








NO	Name	QTY
1	S3 hex wrench	1
2	spout body	1
3	hand shower	1
4	hose	1
5	rossette	1
6	S5 hex wrench	1
7	water inlet pipe	2
8	hex bolt	4
9	washer	4
10	fixing nut	1
11	expansion anchor bolts	4
12	base	1
13	Plug sets	1




fix the screw position




connect water pipes




push the rossette smoothly down to the ground



install the hand shower sets



1. Lift up the handle, water comes out from the spout.
2. turn the handle in a clockwise direction, water temperature change from cold to hot.



- Turn the handle in a counter-clockwise direction, water comes out from hand shower, temperature change from cold to hot by turning.